



ITEM	QTY	DESCRIPTION	AV-01 PART/No.	AV-03 PART/No.	AV-05 PART/No.	AV-08 PART/No.	AV-10 PART/No.	AV-20 PART/No.	AV-35 PART/No.	
1	1	HOUSING	AV-01-01	AV-03-01	AV-05-01	AV-08-01	AV-10-01	AV-20-01	AV-35-01	
2	1	PISTON ASSEMBLY	REFER TO 'A' SEE BELOW							
3	1	END CUP	AV-01-34	AV-03-34	AV-05-34	AV-08-34	AV-10-34	AV-20-34	AV-35-34	
4	1	DISENGAGEMENT LEVER (R/L)	AV-01-15A	AV-03-15A	AV-05-15A	AV-08-15A	AV-10-15A	AV-20-15A	AV-35-15A	
4-A	1	DISENGAGEMENT LEVER PIVOT SHAFT	AV-01-15B	AV-03-15B	AV-05-15B	AV-08-15B	AV-10-15B	AV-20-15B	AV-35-15B	
4-B	1	REACTION PAWL PUSH PIN SPRING	AV-01-18	AV-03-18	AV-05-18	AV-08-18	AV-10-18	AV-20-18	AV-35-18	
5	1	REACTION PAWL	REFER TO 'C' SEE BELOW							
6	1	REACTION PAWL PUSH PIN	AV-01-42	AV-03-42	AV-05-42	AV-08-42	AV-10-42	AV-20-42	AV-35-42	
7	1	SQUARE DRIVE	REFER TO 'G' SEE BELOW							
8	1	RATCHET	AV-01-06	AV-03-06	AV-05-06	AV-08-06	AV-10-06	AV-20-06	AV-35-06	
9	2	DRIVE PLATES (LEFT/ RIGHT)	AV-01-04	AV-03-04	AV-05-04	AV-08-04	AV-10-04	AV-20-04	AV-35-04	
10	1	DRIVE PAWL	REFER TO 'F' SEE BELOW							
11	1	SHROUD	AV-01-31	AV-03-31	AV-05-31	AV-08-31	AV-10-31	AV-20-31	AV-35-31	
12	1	UNISWIVEL ASS'Y	REFER TO 'E' SEE BELOW							
13	1	ROD PIN	AV-01-19	AV-03-19	AV-05-19	AV-08-19	AV-10-19	AV-20-19	AV-35-19	
14	1	DRIVE RETAINER ASS'Y	AV-01-11	AV-03-11	AV-05-11	AV-08-11	AV-10-11	AV-20-11	AV-35-11	
15	1	DRIVE SPLINE SLEEVE ASS'Y	AV-01-07	AV-03-07	AV-05-07	AV-08-07	AV-10-07	AV-20-07	AV-35-07	
16	1	REACTION ARM	AV-01-03	AV-03-03	AV-05-03	AV-08-03	AV-10-03	AV-20-03	AV-35-03	
17	1	UNISWIVEL CAP	AV-01-001P	AV-03-001P	AV-05-001P	AV-08-001P	AV-10-001P	AV-20-001P	AV-35-001P	
18	1	DRIVE PLATE RETAINING RING BACKUP WIRE	AV-01-20	AV-03-20	AV-05-20	AV-08-20	AV-10-20	AV-20-20	AV-35-20	
19	1	DRIVE PLATE RETAINING RING	AV-01-30	AV-03-30	AV-05-30	AV-08-30	AV-10-30	AV-20-30	AV-35-30	
20	1	SQ DRIVE SET SCREW	AV-01-5A	AV-03-5A	AV-05-5A	AV-08-5A	AV-10-5A	AV-20-5A	AV-35-5A	
21	1	REACTION ARM SET SCREW	AV-01-22	AV-03-22	AV-05-22	AV-08-22	AV-10-22	AV-20-22	AV-35-22	
22	2	UNISWIVEL COVER SCREW	AV-01-13	AV-03-13	AV-05-13	AV-08-13	AV-10-13	AV-20-13	AV-35-13	
23	2	DRIVE PAWL SPRING PIN	AV-01-40	AV-03-40	AV-05-40	AV-08-40	AV-10-40	AV-20-40	AV-35-40	
24	1	DRIVE PAWL SPRING	AV-01-27	AV-03-27	AV-05-27	AV-08-27	AV-10-27	AV-20-27	AV-35-27	
25	2	ACCESS PLUG WITH O-RING	AV-01-02	AV-03-02	AV-05-02	AV-08-02	AV-10-02	AV-20-02	AV-35-02	
26	1	SHROUD SPRING	AV-01-59	AV-03-59	AV-05-59	AV-08-59	AV-10-59	AV-20-59	AV-35-59	
27	1	SHROUD SPRING SCREW	AV-01-58	AV-03-58	AV-05-58	AV-08-58	AV-10-58	AV-20-58	AV-35-58	
28	2	DISENGAGEMENT LEVER SCREW	AV-01-39	AV-03-39	AV-05-39	AV-08-39	AV-10-39	AV-20-39	AV-35-39	
29	2	SHROUD SCREW	AV-01-32	AV-03-32	AV-05-32	AV-08-32	AV-10-32	AV-20-32	AV-35-32	
30	2	REACTION PAWL PIN SET SCREW	AV-01-65	AV-03-65	AV-05-65	AV-10-65	AV-10-65	AV-20-65	AV-35-65	
31	1	REACTION PAWL PIN	AV-01-43	AV-03-43	AV-05-43	AV-08-43	AV-10-43	AV-20-43	AV-35-43	
32	1	MALE COUPLER	090155	090155	090155	090155	090155	090155	090155	
33	1	FEMALE COUPLER	090156-1	090156	090156	090156	090156	090156	090156	
34	1	NIPPLE	090103	090101	090101	090101	090101	090101	090101	

ITEM	ASSEMBLIES AND KITS	PART No.	PART No.	PART No.	PART No.	PART No.	PART No.	PART No.
A	PISTON ASSEMBLY	AV-01-25	AV-03-25	AV-05-25	AV-10-25	AV-10-25	AV-20-25	AV-35-25
B	HOUSING SEAL KIT	AV-01-62	AV-03-62	AV-05-62	AV-10-62	AV-10-62	AV-20-62	AV-35-62
C	REACTION PAWL ASS'Y	AV-01-10	AV-03-10	AV-05-10	AV-10-10	AV-10-10	AV-20-10	AV-35-10
D	DISENGAGEMENT LEVER ASS'Y	AV-01-15	AV-03-15	AV-05-15	AV-10-15	AV-10-15	AV-20-15	AV-35-15
E	UNISWIVEL ASS'Y	AV-01-001	AV-03-001	AV-05-001	AV-10-001	AV-10-001	AV-20-001	AV-35-001
E-1	UNISWIVEL SEAL KIT	AV-01-00	AV-03-00	AV-05-00	AV-10-00	AV-10-00	AV-20-00	AV-35-00
F	DRIVE PAWL ASS'Y	AV-01-63	AV-03-63	AV-05-63	AV-10-63	AV-10-63	AV-20-63	AV-35-63
G	SQUARE DRIVE ASS'Y	AV-01-05	AV-03-05	AV-05-05	AV-10-05	AV-10-05	AV-20-05	AV-35-05